

PARALLELS

WALL

INSTALLATION INSTRUCTIONS


SKU - RP-E-2104

REVISION 27.05.21

REVISED BY: JC

Rakumba

- 1** Remove steel bracket from wall light. Pass flexes through bracket, connect to mains (if **internal driver**) or driver output (if **remote driver**). If mains connection, earth point on bracket must also be connected. Push wiring back into wall.



- 2** Screw fix the bracket to wall, use level to ensure straight mounting (fasteners not supplied).



- 3** Tighten top and bottom grub screws until fitting is secured.



- 4** Check straightness. Loosen and adjust as needed.

