

PARALLELS

CARE INSTRUCTIONS

CODE-RP-E-2104

REVISION 17.05.21

REVISED BY: JC

Rakumba



Thank you for choosing Rakumba. We hope you continue to enjoy your light for years to come. To ensure the longevity of your new product, please read the following important information.

Anodised and Powdercoated Surfaces

Both the Anodised and Powdercoated surface options are durable and easy to clean finishes. Avoid touching with bare hands to prevent fingerprints from accumulating, but should these occur, they are easy to clean off following the maintenance routine below.

Maintenance Care

1. Regularly remove dust with a clean, dry cloth or dusting wand, particularly from top of light. Optic Tips have a small air-flow gap around the optic itself, and blank top tips have a small row of air-flow holes. To ensure the LED lifespan is prolonged, keep these air-flow passages free from dust and insects.
2. To remove fingerprints from the anodised or powdercoated finishes use a non-abrasive window cleaner sprayed onto a soft cloth. Never spray liquid cleaners directly onto the light fitting. For particularly stubborn marks, methylated spirits may be used.